

KENT TOOLING DIVING PRODUCTS RATCHET REEL TRIGGER OPERATION INSTRUCTIONS

IMPORTANT: PLEASE READ BEFORE USE

Your reel has been set in the standard ratchet configuration where you will need to depress the trigger to release the line.



To put your reel into free spool mode, please lift the black trigger knob and rotate a quarter turn and drop it into its opposite castellation slot, then depress the trigger down once to engage the pin into the location hole, your reel is now in free spool mode and your line will be able to spool unaided.

To return the reel back in to the standard ratchet configuration just repeat the step above by lifting the black trigger knob and return it to its original position.

Please be aware that the line has already been tied securely to one of the inner spool supports.

If you have any queries regarding the above, please do not hesitate to contact us on +44(0)1227 700374 or via e-mail on sales@divingproducts.co.uk.